

Pattern Information

Date: 4-Feb-15
 Pattern Type:
 Pattern Difficulty:
 Pattern Designer:
 Pattern Volume (ml): 22,21

Surface Information

Surface Type: Synthetic
 Surface Brand: Brunswick Pro Lane
 Age: 9

Pattern Parameters


Pattern Number:
 Pattern Name: Ranking Tali 28.2.2015
 Mode: Clean & Oil
 Forward Speed: Max Clean
 Start Cleaner Spray: 0
 Start Squeegee: 0
 Start Oiling: 6
 Split Pattern:
 Notes: _____

Supplies Information

Lane Cleaner:
 Cleaner Mixture Ratio: : 1
 Cleaner Transition Distance: 45 Authority22
 Cleaner Spray End Distance: 53 Envoy
 Lane Conditioner: DEFY

Zone	1	2	3	4	5	6	7	8
Zone End Distance	9	18	28	33	39	47		
Zone Ratio	L 1,9 : 1	2,3 : 1	2,5 : 1	2,0 : 1	1,6 : 1	### : 1	### : 1	### : 1
	R 1,9 : 1	2,3 : 1	2,5 : 1	2,0 : 1	1,6 : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	9,62	6,96	3,77	1,15	0,71	0,00	0,00	0,00

ZONE	7 Pin Side																	Board Number												10 Pin Side											
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1		
1	35	35	35	50	50	50	50	50	65	65	65	85	85	90	90	90	90	90	90	90	90	85	85	85	85	65	65	65	65	65	50	50	50	50	50	35	35	35			
2	30	30	30	30	30	30	40	40	40	40	40	40	65	65	75	75	75	75	75	75	75	65	65	65	40	40	40	40	40	40	40	40	30	30	30	30	30	30	30		
3	15	15	15	15	15	15	15	15	15	15	20	25	30	30	30	40	40	40	40	40	30	30	30	30	30	25	20	15	15	15	15	15	15	15	15	15	15	15	15		
4	10	10	10	10	10	10	10	10	10	10	10	15	20	20	20	20	20	20	20	20	20	20	20	20	20	20	15	10	10	10	10	10	10	10	10	10	10	10	10		
5	6	6	6	6	6	6	6	6	6	6	6	6	6	6	10	10	10	10	10	10	10	10	10	10	10	6	6	6	6	6	6	6	6	6	6	6	6	6			
6	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		
7																																									
8																																									





Ranking Tali 28.2.2015

Crosswise Ratios (by units)

Zone 1				Zone 5			
	Average	Ratio		Average	Ratio		
3L-7L	Left = 47,0	1,9	3L-7L	Left = 6,0	1,6		
3R-7R	Right = 47,0	1,9	3R-7R	Right = 6,0	1,6		
18L-18R	Center = 90,0		18L-18R	Center = 10,0			
Zone 2				Zone 6			
3L-7L	Left = 32,0	2,3	3L-7L	Left = 0,0	#####		
3R-7R	Right = 32,0	2,3	3R-7R	Right = 0,0	#####		
18L-18R	Center = 75,0		18L-18R	Center = 0,0			
Zone 3				Zone 7			
3L-7L	Left = 15,0	2,5	3L-7L	Left = #####	#####		
3R-7R	Right = 15,0	2,5	3R-7R	Right = #####	#####		
18L-18R	Center = 38,0		18L-18R	Center = #####			
Zone 4				Zone 8			
3L-7L	Left = 10,0	2,0	3L-7L	Left = #####	#####		
3R-7R	Right = 10,0	2,0	3R-7R	Right = #####	#####		
18L-18R	Center = 20,0		18L-18R	Center = #####			

Crosswise Ratios (by ml)

Zone 1				Zone 5			
	Average	Ratio		Average	Ratio		
3L-7L	Left = 0,177	1,9	3L-7L	Left = 0,015	1,6		
3R-7R	Right = 0,177	1,9	3R-7R	Right = 0,015	1,6		
18L-18R	Center = 0,340		18L-18R	Center = 0,025			
Zone 2				Zone 6			
3L-7L	Left = 0,121	2,3	3L-7L	Left = 0,000	#####		
3R-7R	Right = 0,121	2,3	3R-7R	Right = 0,000	#####		
18L-18R	Center = 0,283		18L-18R	Center = 0,000			
Zone 3				Zone 7			
3L-7L	Left = 0,063	2,5	3L-7L	Left = 0,000	#####		
3R-7R	Right = 0,063	2,5	3R-7R	Right = 0,000	#####		
18L-18R	Center = 0,159		18L-18R	Center = 0,000			
Zone 4				Zone 8			
3L-7L	Left = 0,021	2,0	3L-7L	Left = 0,000	#####		
3R-7R	Right = 0,021	2,0	3R-7R	Right = 0,000	#####		
18L-18R	Center = 0,042		18L-18R	Center = 0,000			

The crosswise ratios are calculated by the average units of oil for boards 18L - 18R and divided by the average units of oil for board 3 - 7 left and right.

