



ENVOY



AUTHORITY22®

Select Machine

Pattern Information

Date: 21-May-15
 Pattern Type: Sport
 Pattern Difficulty: High
 Pattern Designer: Brunswick
 Pattern Volume (ml): 25.77

Pattern Parameters

Pattern Number: []
 Pattern Name: WTBA ATLANTA
 Mode: Clean & Oil
 Forward Speed: Max Clean
 Start Cleaner Spray: 0
 Start Squeegee: 0
 Start Oiling: 6
 Split Pattern: No

Supplies Information

Lane Cleaner: []
 Cleaner Mixture Ratio: : 1
 Cleaner Transition Distance: 40
 Cleaner Spray End Distance: 54
 Lane Conditioner: []


Surface Information

Surface Type: []
 Surface Brand: []
 Age: []

Notes Revised 2015

	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
Zone End Distance	7.5	14.5	30	38				
Zone Ratio	L 2.4 : 1	2.7 : 1	3.0 : 1	### : 1	### : 1	### : 1	### : 1	### : 1
	R 2.1 : 1	2.3 : 1	2.6 : 1	### : 1	### : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	8.96	6.61	10.20	0.00	0.00	0.00	0.00	0.00

ZONE	7 Pin Side																	Board Number																	10 Pin Side																
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1												
1	31	31	31	36	36	51	51	61	61	81	81	96	96	100	100	100	100	100	100	100	100	100	100	100	100	100	100	96	96	81	81	61	61	51	51	36	31	31	31												
2	22	22	22	26	26	38	38	47	47	65	65	77	77	81	81	81	81	81	81	81	81	81	81	81	81	81	81	77	77	65	65	47	47	38	38	26	22	22	22												
3	13	13	13	16	16	25	25	32	32	46	46	55	55	58	58	58	58	58	58	58	58	58	58	58	58	58	55	55	46	46	32	32	25	25	16	13	13	13													
4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0												
5																																																			
6																																																			
7																																																			
8																																																			





ENVOY AUTHORITY22®

WTBA ATLANTA

Crosswise Ratios (by units)

Zone 1	Average	Ratio
3L-7L Left =	41.0	2.4
3R-7R Right =	46.0	2.1
18L-18R Center =	100.0	

Zone 2	Average	Ratio
3L-7L Left =	30.0	2.7
3R-7R Right =	34.2	2.3
18L-18R Center =		

Zone 3	Average	Ratio
3L-7L Left =	19.0	3.0
3R-7R Right =	22.2	2.6
18L-18R Center =	58.0	

Zone 4	Average	Ratio
3L-7L Left =	0.0	#DIV/0!
3R-7R Right =	0.0	#DIV/0!
18L-18R Center =	0.0	

Zone 5	Average	Ratio
3L-7L Left =	#DIV/0!	#DIV/0!
3R-7R Right =	#DIV/0!	#DIV/0!
18L-18R Center =		

Zone 6	Average	Ratio
3L-7L Left =	#DIV/0!	#DIV/0!
3R-7R Right =	#DIV/0!	#DIV/0!
18L-18R Center =		

Zone 7	Average	Ratio
3L-7L Left =	#DIV/0!	#DIV/0!
3R-7R Right =	#DIV/0!	#DIV/0!
18L-18R Center =		

Zone 8	Average	Ratio
3L-7L Left =	#DIV/0!	#DIV/0!
3R-7R Right =	#DIV/0!	#DIV/0!
18L-18R Center =		

Crosswise Ratios (by ml)

Zone 1	Average	Ratio
3L-7L Left =	0.129	2.4
3R-7R Right =	0.145	2.1
18L-18R Center =	0.314	

Zone 2	Average	Ratio
3L-7L Left =	0.088	2.7
3R-7R Right =	0.100	2.3
18L-18R Center =	0.238	

Zone 3	Average	Ratio
3L-7L Left =	0.123	3.0
3R-7R Right =	0.144	2.6
18L-18R Center =	0.377	

Zone 4	Average	Ratio
3L-7L Left =	0.000	#DIV/0!
3R-7R Right =	0.000	#DIV/0!
18L-18R Center =	0.000	


Zone 5	Average	Ratio
3L-7L Left =	0.000	#DIV/0!
3R-7R Right =	0.000	#DIV/0!
18L-18R Center =	0.000	

Zone 6	Average	Ratio
3L-7L Left =	0.000	#DIV/0!
3R-7R Right =	0.000	#DIV/0!
18L-18R Center =	0.000	

Zone 7	Average	Ratio
3L-7L Left =	0.000	#DIV/0!
3R-7R Right =	0.000	#DIV/0!
18L-18R Center =	0.000	

Zone 8	Average	Ratio
3L-7L Left =	0.000	#DIV/0!
3R-7R Right =	0.000	#DIV/0!
18L-18R Center =	0.000	

The crosswise ratios are calculated by the average units of oil for boards 18L - 18R and divided by the average units of oil for board 3 - 7 left and right.



3L-7L:18L-18R

2.73

Ratio by Total Volume

1

18L-18R:7R-3R

2.39



Lengthwise Ratio By Area

	3L-7L	18L-18R	3R-7R
	Left	Center	Right
Zone 2	1.3	1.2	1.3
Zone 3	2.1	1.7	2.0
Zone 4	#DIV/0!	#DIV/0!	#DIV/0!
Zone 5	#DIV/0!	#DIV/0!	#DIV/0!
Zone 6	#DIV/0!	#DIV/0!	#DIV/0!
Zone 7	#DIV/0!	#DIV/0!	#DIV/0!
Zone 8	#DIV/0!	#DIV/0!	#DIV/0!

WTBA ATLANTA

Lengthwise Ratio By Board (units & ml)

Zone	7 Pin Side														Board Number												10 Pin Side													
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1	
2	1.4	1.4	1.4	1.4	1.4	1.3	1.3	1.3	1.3	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.2	1.3	1.3	1.3	1.3	1.4	1.4	1.4	1.4		
3	2.4	2.4	2.4	2.3	2.3	2.0	2.0	1.9	1.9	1.8	1.8	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.7	1.8	1.8	1.9	1.9	2.0	2.0	2.3	2.4	2.4	2.4		
4	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###
5	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###
6	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###
7	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###
8	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###	###

The lengthwise ratios are calculated from the volumes in the first zone.